


SA420 Signal Conditioner



Description:

Electro-Sensor's SA420 Signal Conditioner provides an analog signal directly proportional to the speed of a monitored shaft. The 0-10 VDC and 4-20 mA outputs can be sent to a chart recorder, digital display, PLC, loop controller, drive speed controller, or other control or monitoring devices. The wide voltage range and wave shape flexibility of the SA420's sensor input circuitry allow it to translate signals from Hall-Effect Sensors, proximity switches, magnetic sensors, and a wide variety of other pulse generator devices into analog outputs.

Sensor Installation:

The standard sensor is supplied with a mounting bracket and two jam nuts. The explosion-proof sensor is supplied with a slotted mounting bracket. Sensors should be installed so the centerline of the magnets pass in front of the center of the sensor as the disc or wrap rotates. When using the pulser disc, the center of the magnetized area of the disc, shown as Dimension B in figures 1 and 3, is 1-3/4 inches from the center hole of the disc. The gap distance between the sensor and the disc or wrap, Dimension A in the diagrams, is 1/4-inch \pm 1/8 inch. To achieve the proper gap distance, adjust the jam nuts holding the standard sensor in the mounting bracket, or adjust the position of the explosion-proof sensor using the slots on its mounting bracket.

Pulser Disc:

The end of the shaft to be monitored must be center drilled to a depth of 1/2-inch with a No. 21 drill and tapped for 10-32UNF. After applying Loctite™ or a similar adhesive on the threads to keep the pulser disc tight, the pulser disc should be attached, decal side out, with the supplied 10-32UNF machine screw and lock washer.

Pulser Wrap (optional):

Pulser Wraps are custom manufactured to fit the shaft they will be mounted on. When the wrap is shipped, four Allen-head cap screws hold the two halves of the wrap together. These screws must be removed so that the wrap is in two halves. Place the halves around the shaft, reinsert the screws and torque them to 5 foot-pounds max.




Figure 1: Standard Sensor with 255 Pulser Disc




Figure 2: Standard Sensor with optional Pulser Wrap




Figure 3: Explosionproof Sensor with 255 Pulser Disc




Figure 4: Explosionproof Sensor with Pulser Wrap

SA420 Signal conditioner

For version 3 hardware with version 5.xx or later firmware

The SA420 now includes the following features:

- Quadrature (directional decoding)
- Bipolar voltage output (units now include +/- 5 VDC and +/- 10 VDC)
- Optional higher NPN input signal trip point (improves operation through IS barrier)
- Programmable lower analog output setpoint (Previously fixed at 0 Hz, now includes forward and reverse offsets) PR (00)
- Programmed to power up and display in the following units PR (04):
 - Hz (default)
 - Percent of maximum output
 - User defined units
- Programmable minimum frequency cutoff. PR (05) (This allows you to decide where the unit zeroes out for faster zeroing)
- More modes of operation:
 - Single channel
 - Quadrature 1X
 - Single channel 2X (new)
 - Quadrature 2X (new)
 - Quadrature 4X (new)
- Security lock variables (viewable but not changeable while locked)
- Ability to improve calibration with user variables which alter the upper and lower calibration point of the analog
- Choice of new menu or revert to basic 3 variable menu for compatibility



Wiring Connections:

Sensor Wire connections:

| Terminal | Model 906/ Old 907 | All other ESI Sensors | Mag Pickup | Logic Level | ESI Prox/ New 907 |
|-------------|--------------------|-----------------------|------------|-------------|-------------------|
| 5 Supply | Red | Red | N/C | N/C | Brown |
| 6 Signal | Black | Clear | + | Signal | Black |
| 7 Ground | Clr/Shd | Blk/Shd | - | Common | Blue |
| 11 Signal B | Green | Green | N/C | N/C | White |


Power Connections:

| Terminal | 115 VAC Standard | 230 VAC Optional | 12 VDC Optional | 24 VDC Optional |
|----------|------------------|------------------|-----------------|-----------------|
| 2 | Hot | L1 Hot | (+)Positive | (+)Positive |
| 10 | Neutral | L2 Hot | (-)Negative | (-)Negative |

Analog Output Connections:

| Terminal | 4-20 mA |
|----------|----------|
| 3 | (+) High |
| 4 | (-) Low |

| Terminal | 0-10 VDC |
|----------|--------------|
| 9 | (+) Positive |
| 8 | (-) Negative |



| Terminal | Connection |
|----------|-----------------|
| 1 | No Connect |
| 2 | Hot + |
| 3 | 4-20mA + |
| 4 | 4-20mA - |
| 5 | Sensor Supply |
| 6 | Sensor Signal A |
| 7 | Sensor Ground |
| 8 | 0-10 VDC - |
| 9 | 0-10 VDC + |
| 10 | Neutral - |
| 11 | Sensor Signal B |

Figure 5: Terminal Block wiring

Frequency Calculations

Pertinent formula: Frequency (Hz) = (RPM * PPR)/60

Example: A customer has a motor rotating at 1200 RPM and wants the SA420 to output 20mA at 1250 RPM using a Hall Effect sensor and an ESI 255 disc.

Since the Hall Effect sensors turns on with a south field and off with a north field, the 255 disc's 16 alternating magnets (8 north and 8 south fields) will produce 8 PPR (Pulses Per Revolution). Insert 8 into the equation for PPR.

$$F = (1250 * 8) / 60$$

$$F = 166.7 \text{ Hz [Value used in PR (01)]}$$

Programming:

There are four buttons on the front panel used for calibration:

▲ Up Arrow Button is used to change the value of the position in focus (flashing), while in the calibration mode. While in standard mode, this button will toggle the display between frequency input (hertz) and output percentage.

◀ Left arrow button is used to move the focus to the next position when in the calibration mode of 4-20 mA or 0-10 VDC.


● Decimal Point Button is used to change the position of the decimal point while in the calibration mode.

ENT Enter Button is used to enter or exit the calibration mode.

Programming The Unit:

Standard menu: To enter the calibration mode, push the ENT button once. PR0 will be displayed. Press the ▲ (up) button to increment to the desired variable. Press the ENT button at which time the value of variable is displayed. The right most digit of the variable will be flashing, which indicates that this digit has the focus and can be changed. Pressing the ▲ (up) button will increment the flashing digit. The ◀ button will advance the focus to the next digit to be changed. The • (DP) button will scroll the decimal point across the display from right to left if that variable has the decimal point enabled. When the correct value is programmed into the variable, press the ENT button to store the variables value in memory. The display will show PRxx (the variable you just updated). You can now ▲ (up) button to the next variable you wish to change or continue until you've reached the end of variables and exit to user mode.

Basic menu: To enter the calibration mode, push the ENT button once. PR1 will be displayed for one second, and then the value of variable 1 is displayed. This is the Max frequency value. the right most digit of variable 1 will be flashing, which indicates that this digit has the focus and can be changed. Pressing the ▲ button will increment the flashing digit. The ◀ button will advance the focus to the next digit to be changed. The • (DP) button will scroll the decimal point across the display from right to left. When the correct value is programmed into the variable, press the ENT button to store the variable into memory and access variable Pr02. Pr02 is the sensor type. You can now change Pr02 to match the sensor output type if necessary or press the ENT button and advance to Pr03. Pr03 contains the input pulse buffer. When the value is correct press the ENT button to save value and to return to the user mode.



Variable functions

PR (00) Analog Lower Setpoint*

Setpoint for 4mA and 0 VDC value. (-5 or -10VDC if selected). To represent a reverse rate, increment the left most digit until the rate icon flashes. **

PR (01) Analog Upper Setpoint*

Setpoint for 20mA and 10 VDC value. (5 VDC or 10 VDC if selected). To represent a reverse rate, increment the left most digit until the rate icon flashes. **

PR (02) Sensor Type and Level

Used to select your sensor output type. The default is set to 0.

| Variable 2 Value | Type of Sensors |
|------------------|-----------------|
| 0 | NPN* |
| 1 | PNP |
| 2 | Magnetic Pickup |
| 3 | Logic Level |
| 4 | NPN 6.5V |
| 5 | PNP 6.5V |

**(All Standard ESI sensors are NPN open collector output.)*

PR (03) Buffer Size

Ring buffer filtering up to 600 pulses. It is a first-in-first-out configuration. Typically, you would put in the PPR of the sensor/target combination or a supermultiple of the PPR.

Example: Customer using 906 sensor (Hall type with 1 PPR per 2 magnets) and a 255 disc (16 alternating magnets) would generate 8PPR. Normally you would use 8, 16, 24, 32... for the buffer size. Using higher counts makes the output more stable but slows the response down. You need to strike a balance between buffer size and response.

PR (04) User Units

Value to be displayed when operating at PR (01) frequency. (FPM, RPM, etc.) this is the value to display when operating at the frequency entered in variable Pr01.

PR (05) Frequency Cutoff

User can set the frequency cutoff to zero the unit faster. Customers that are reading higher speeds may want to raise the value entered here to quickly zero the unit out. conversely customers that need to read lower speeds may want to reduce this number, so it doesn't zero out too soon.

PR (06) Analog Response

Some applications need slower analog response rates. This variable is where you set the time required to slew from 10-90% analog output

PR (07) Signal Type**

Programming of PR (07) determines the way the signals are handled. There are multiple choices for both single and quadrature operation. 1X uses the rising edge of channel "A". 2X uses the rising and falling edge of channel "A". the quadrature 4X uses both the rising and falling edges of both the "A" and "B" channels. When using 2X or 4X configurations the PPR calculations will be double or quadruple verses the 1X configuration and the user needs to increase the Pr01 (Analog upper setpoint) value upward accordingly.

PR (08) Voltage Output Type

Controls the type of voltage output from the unit. There are multiple options see the table in the variable table on page 6.

PR (09) Menu Option

Controls what program menu is used. User can choice between the current advanced menu or revert for compatibility to the basic menu which has three variables.

All units will start in the new advanced menu unless the user programs it to use the basic menu. A user can get it back to the advanced menu which is the standard menu now by: holding down the decimal button and left arrow button simultaneously while powering on the unit. Then change PR (09) from (0000) to (0001) and press enter. The advanced menu will remain afterwards when restarting the unit.

Keep in mind that advanced features will be retained if you switch from the advanced menu back to the basic menu until you reset the unit. If you change PR (09) to zero (0000) the variables will remain but only PR (01) through PR (03) will be viewable.

PR (10) Display Option

User can set how the feedback is displayed. This enables the display of user to set in user units

PR (11 thru 14) Reserved

PR (15) Security PIN

To advance past this point when going through the menu this PIN must match the password. This will make the variable Read/Write rather than read only.

PR (16) Security Password

User can lock variables. Making PR (15) different from PR (16) will lock the variables and make PR (16) unviewable. It is important to remember the number entered in PR (16).

PR (17) Cal: PIN

To advance past this point when going through the menu this PIN must match the password. This will make the Cal variables accessible.

PR (18) CAL: Password

User can update variables 10-22 if the Cal pin matches the Cal password. Making PR (17) different from PR (18) will lock the calibration variables and make PR (18) unviewable. It is important to remember the number entered in PR (18).

PR (19) CAL: Voltage offset value

Setting that allows the user to adjust the Voltage offset to obtain greater accuracy.

Not implemented yet

PR (20) CAL: Voltage gain value

Setting that allows the user to adjust the Voltage gain to obtain greater accuracy.

Not implemented yet

PR (21) Cal: Current offset value (4.000mA)

Setting PR21 allows the user to adjust the current offset to obtain greater accuracy. The adjustment value is approximately 366nA (0.000366uA) of deviation up or down per single count of change. Example of changing this from 1000 to 980 results in the analog decreasing. It will decrease (20 * 0.000366uA) or -0.00732uA. When done after the initial warm up of the unit, about 15 minutes, it can dramatically increase the accuracy of the unit.

PR (22) Cal: Current gain value (20.000mA)

Setting Pr22 allows the user to adjust the current gain value to obtain greater accuracy. The adjustment value is approximately 366nA (0.000366uA) of deviation up or down per single count of change. Example: Changing this value from 1000 to 1010 will result in the analog output increasing. It will increase (10 * 0.000366uA) or 0.00366uA. When done after the initial warm up of the unit, about 15 minutes, it can dramatically increase the accuracy of the unit.

*Users can program the analog to go up or down as the frequency increases by swapping the lower setpoint [PR (01)] with their upper setpoint [PR (00)].

**Reverse numbers are represented by a flashing “rate” icon and cannot be programmed until PR (07) is set for quadrature operation.

SA420 Advanced Mode Variables

| Variable Number and Name | Default Value | Value Range | Coded Number Table | Move Decimal | User Values |
|--|---------------|--------------|--|--------------|-------------|
| (00) ANALOG_LOWER_SP_VAR | 0 | any number * | | Yes | |
| (01) ANALOG_UPPER_SP_VAR | 240.0 | any number * | | Yes | |
| (02) SENSOR_TYPE_VAR | 0000 | 0-5 | 0 = NPN (2.5 VDC trip level) 1 = PNP (2.5 VDC trip level) 2 = Mag (75 mVDC trip level) 3 = Logic (2.5 VDC trip level) 4 = NPN (6 VDC trip level)** 5 = PNP (6 VDC trip level)** | No | |
| (03) BUFFER_SIZE_VAR | 8 | 0-16 | | No | |
| (04) USER_UNITS_VAR | 1800 | any number * | | Yes | |
| (05) FREQUENCY_CUTOFF_VAR | 0.5 | 0.0-10.0 Hz | | No | |
| (06) ANALOG_RESPONSE_VAR | 00.00 | 00.00-20.00 | Amount of time it takes the analog output to change from 10% to 90% Examples: 00.00 or 00.01 = 00.01 seconds 00.10 = 0.10 seconds 00.50 = 00.50 seconds | No | |
| (07) SIGNAL_TYPE_VAR | 0 | 0-4 | 0 = Single channel operation 1 = Quadrature operation 2 = Single channel 2X operation 3 = Quadrature operation 2X 4 = Quadrature operation 4X | No | |
| (08) VOLTAGE_OUTPUT_TYPE VAR | 1 | 0-3 | 0 = 0-5 VDC 1 = 0-10 VDC 2 = +/- 5 VDC 3 = +/- 10 VDC | No | |
| (09) MENU_OPTION_VAR | 1 | 0-1 | 0 = Basic menu 1 = Advanced menu (Standard) | No | |
| (10) DISPLAY_OPTION_VAR | 0 | 0-2 | 0 = Hz 1 = Percent output 2 = User units | No | |
| (11) reserved for future use (12) reserved for future use (13) reserved for future use (14) reserved for future use | | | | No | |
| (15) SECUR_PIN_VAR | 0420 | 0000-9999 | | No | |
| (16) SECUR_PASS_VAR | 0420 | 0000-9999 | | No | |
| (17) SECUR_CAL_PIN_VAR | 0 | 0000-9999 | | No | |
| (18) SECUR_CAL_PASS_VAR | 0420 | 0000-9999 | | No | |
| (19) CAL: VOLTAGE_OFFSET | 1000 | 0000-2000 | Currently not active | No | |
| (20) CAL: VOLTAGE_GAIN | 1000 | 0000-2000 | Currently not active | No | |
| (21) CAL: CURRENT_OFFSET | 1000 | 0000-2000 | | No | |
| (22) CAL: CURRENT_GAIN | 1000 | 0000-2000 | | No | |

* When the 'rate' icon is flashing, the number being programmed is a reverse direction value. A value can only be displayed as a reverse direction value AFTER the unit is programmed to operate in quadrature mode. This prevents errant reverse values from being entered into a single-channel unit.

** Recommended quadrature setting for NPN or PNP.



SA420 Dimensional Drawings:
Dimensions in Inches




Figure 6: SA-420




Figure 7: Terminal Block




Figure 8: 255 Pulsar Disc




Figure 9: Standard Sensor




Figure 10: Explosionproof Sensor




Figure 11: Explosionproof Sensor Bracket

Troubleshooting Guide

| Problem | Possible Solution |
|---|---|
| Unit Dead | Check for proper supply at terminals 2 and 10. See figure 5 on page 3 |
| No Analog out with zero hertz displayed | Check for Sensor supply. It should be Approximately 13.6 VDC |
| | Check sensor Gap distance |
| | Check Sensor Type (Variable 2) |
| Unit displays a frequency but the analog is incorrect | Check variable 1 for correct frequency |
| | Check your on the correct analog output, voltage(VDC) or current(mA) |
| Analog is unstable | Check gap distance |

SA420 General Specifications:

| Input Power | Input Current | Fuse Type (F2) |
|---------------------|---------------|-------------------|
| 115 Vac, 60Hz (std) | 2.5 VA | Sloblo .032A 5X20 |
| 230 Vac, 60Hz (opt) | 2.5 VA | Sloblo .032A 5X20 |
| 12 Vdc (opt) | 165 mA | Sloblo .250A 5X20 |
| 24 Vdc (opt) | 135 mA | Sloblo .200A 5X20 |

| Input Signal | Parameters |
|-------------------------------------|---|
| Sensor Supply | 12 VDC (unregulated) @50 mA max. |
| Programmable Types | Open collector NPN / PNP Logic Level 5 V Nom. 3 V Min. Magnetic Sensor +/- 75 MV Min. |
| Max. Amplitude | 25 Vpk-pk Maximum |
| Frequency Range | 0.01 Hz to 10 kHz |
| Minimum Input for Full Scale Output | 0.5 Hz = 3.8 RPM @ 8 PPR (Lower full scale range is available, consult Factory) |

| Analog Output Signal | Parameters |
|----------------------|---|
| Types | 0 - 10 VDC, 4 - 20 mA with 500Ω load max. |
| Accuracy (typical) | 0.1% Linearity for both outputs |



| Step Response Time | Parameters |
|-----------------------|--|
| 50 Hz Input and above | 10 to 90% = 50 ms. |
| Below 50 Hz Input | 10 to 90% = 30 ms + 1/Hz Input frequency |

| Physical/Environment | Parameters |
|---------------------------|-------------------------------------|
| Mounting | DIN rail mount or Stand alone |
| Operating temperature | 0°C to +60°Cz |
| Storage temperature | -65°C to +125°C |
| Electrical Connections | 11 Position DIN rail terminal block |
| DIN rail enclosure rating | NEMA 1 |

| 255 Pulser Disc (std.) | Parameters ** |
|------------------------|--|
| Material | Nylon 12 Std, (opt; PVC, Alum, Stainless-Steel) |
| Dimensions | 4-inch diameter x 1/4-inch thick |
| Operating Temperature | -40°C to +60°C* (Nylon, PVC) |
| Operating Temperature | -40°C to +150°C* (Alum, SS) |

| Pulser Wrap (optional) | Parameters ** |
|------------------------|--|
| Material | PVC Std. (opt; Aluminum or Stainless-Steel) |
| Operating Temperature | -40°C to +60°C* (PVC) |
| Operating Temperature | -40°C to +150°C* (Aluminum, SS) |

| 906 Sensor (Standard) | Parameters ** |
|------------------------|---|
| Material Sensor Body | Aluminum 3/4 - 16UNF thread |
| Material Mount Bracket | Plate steel |
| Output Types | NPN open collector current sinking 20 mA max |
| Signal Cable | 3-conductor shielded, 10 feet length std. (50 ft. or 100 ft. optional) |
| Operating Temperature | -40°C to + 60°C* |
| Air Gap | 1/4 inch +/- 1/8 inch with standard 255 Pulser disc (1/2" magnets) |

| 907 Explosionproof Sensor (optional) | Parameters ** |
|--|---|
|  | Class I, Div 1, Group D Class II, Div 1, Groups E, F, G UL File: E249019 |
| |  |
| Mounting Bracket Material | Plate Steel U-Bolt Assembly |
| Other Specifications | Similar to 906 standard sensor |

Specifications are subject to change without notice.

***For higher or lower temperature ranges, consult factory.**

**** For details on Discs, Wraps and Sensors, consult factory or visit our website.**