


## MM-1.25 Mounting Magnet Installation Instructions

For use with the EZ-3/4in or EZ-18mm



### Installation procedure:

1. Remove cover of EZ-3/4in or EZ-18mm (3 screws).
2. Put 1/2" machine bushing and 1/2" lock washer onto shaft of EZ-3/4in or EZ-18mm as shown above.
3. Apply Loctite® 242 or equivalent to threads of shaft and inside MM-1.25 mounting magnet.
4. Tighten MM-1.25 mounting magnet onto shaft of EZ-3/4in or EZ-18mm using 3/8" hex wrench and adjustable jaws pliers or pipe wrench. Torque to 5 ft-lbs. Allow to cure for 2 hours before use.
5. Put on cover (3 screws).
6. Lightly grease end of shaft with silicone grease to assist in centering mounting magnet.
7. Remove protective metal disc and spacer from face of magnet.
8. Carefully install unit onto center of the monitored shaft end. Magnet is very strong, avoid pinching fingers!
9. Attach holding strap to a secure location.

**Proper lock-out and tag-out procedures must be followed during the installation procedure. The shaft must be stopped during the entire installation process. The mounting magnet is very powerful. Keep all sensitive devices such as credit cards away from the magnet since they can be damaged. Do not allow hands, fingers, or tools to come between the magnet and any ferrous material, serious injury could result.**